

INSTALLATION INSTRUCTIONS

1481 - TO SUIT HONDA LEGEND 4 DOOR 5/96-ON

PLEASE READ INSTRUCTIONS THROUGH BEFORE YOU BEGIN

WARNING : 1. Do not drill, cut weld or otherwise modify the towbar.

2. If you are using electric welding on a motor vehicle, always check that the vehicle is not equipped with electronic engine or instrument management equipment. Failure to do so could destroy any onboard computers. If in doubt, check with the vehicle's manufacturer.

1. Ensure all hardware items have been included.
2. Remove bumper bar.
Five plastic trim buttons in between tail lights
Two plastic trim buttons from under car at rear
Two screws and one button at each wheel arch
3. Remove steel impact beam - 2 bolts each side inside of boot compartment.
4. Remove spare wheel.
5. Hold towbar up to vehicle as to align with holes in each sub frame and support.
6. Fit bolts and plates on wire through end of sub frames into three holes each side. Tighten to torque listing below.
7. Using 11mm drill, drill hole into spare wheel well, using hole in tail of towbar as a guide.
8. Open top hole only to take spacer tube.
9. Fit bolt, plate and spacer tube as per sketch. Tighten to torque listing below.
10. Refit steel impact beam, bumper bar and spare wheel.
11. Towbar rating sticker to be conspicuously located on inside rear end of the driver's door.
(see diagram below)

RECOMMENDED ASSEMBLY TORQUE LISTING

<u>Diameter</u>	<u>Grade 4.6 Bolt</u>	<u>Grade 8.8 Bolt</u>
	Nm	Nm
M6	3.5	9.5
M8	8.6	21.7
M10	16.9	43.4
M12	29.8	77.3
M16	74.0	189.8

22.4.96

1481 - TO SUIT HONDA LEGEND 4 DOOR 5/96-ON