

**BORONIA TOWBARS PTY LTD
1/12 EDINA RD
FERNTREE GULLY
VIC 3156
(03) 9752 2642**

**CHR30 FITTING INSTRUCTIONS:
SUITS: PAJERO & ROCKY**

MOUNT TOWBAR TO CENTRE SUPPORT PANEL VIA 4 EXISTING HOLES (3 HOLES WILL BE THREADED, THE LAST HOLE - FIT BOLT SUPPLIED WITH NUT SUPPLIED).
TIGHTEN ALL BOLTS.

FITTING KIT:

4 – 12 x 30mm FINE THREAD BOLTS, SPRING & FLAT WASHERS.
1 – 12mm FINE THREAD NUT ONLY
1 – DEE SHACKLE