

**BORONIA TOWBARS  
1/12 EDINA RD  
FERNTREE GULLY  
VIC 3156  
(03) 9752 2642  
A.C.N. 004 883 336**

**CHR34/39 FITTING INSTRUCTIONS  
MAGNA/GALANT TR/TS SEDAN  
TOWING CAPACITY 1200kg**

PLACE TOWBAR UP TO VEHICLE IN BETWEEN CHASIS USING (10mm) BOLTS SUPPLIED, FIT WITH SPRING WASHERS & FLAT WASHERS INTO EXISTING HOLES IN CHASSIS

DRILL (10mm) REMAINING HOLES VIA TOWBAR INTO BOOT AREA (REMOVE SPARE WHEEL FIRST)

OPEN HOLES IN BOOT TO ACCEPT TUBES SUPPLIED

FIT BOLTS, PLATES & TUBE - TIGHTEN

CHECK ALL BOLTS FOR TIGHTNESS

NOTE:

ON MAGNA T.R. MODELS 1991 - THE EXHAUST RUBBER MUST BE FITTED TO BRACKETS ON TOWBAR.

THE TOW LUG ON THE T.R. MAGNA IS LONGER THAN EARLY MODEL MAGNA TOWBAR.

**FITTING KIT:**

4 - 10mm. x 35mm FINE BOLTS SPRING WASHERS

4 - 10mm FLAT WASHERS

2 - 2 ½ x 3/8 BOLT, NUT, SPRING & FLAT WASHERS

2 - 1 x ½ SLEEVES

2 - 1 ½ x 3 x 3/8 PLATES

1 - DEE SHACKLE