

# TRAILBOSS

Towbar Fitting Instructions  
To Suit MITSUBISHI PAJERO SWB AND LWB 83-ON  
Part Number CL48  
Rating 1250Kg

1. Ensure all hardware items have been included.
2. Remove four bolts and shipping hook from centre of bumper bar.
3. Fit tow bar and shipping hook with bolts and spring washers.
4. Tighten bolts to torque listing below.

## RECOMMENDED ASSEMBLY TORQUE LISTING

<u>Diameter</u>	<u>Grade 8.8 Bolt</u>
	<b>Nm</b>
M6	9.5
M8	21.7
M10	43.4
M12	77.3
M14	121.0
M16	189.8

