



Towbar Fitting Instructions  
To Suit MITSUBISHI LANCER SEDAN AND COUPE 9/92 ON  
SPORTS MODEL VR-X  
Part Number CL56A  
Rating 750Kg

1. Ensure all hardware items have been included
2. Remove bumper bar.
3. Hold towbar up against vehicle and align with tapped holes in chassis.
4. Fit five threaded bolts to these holes.
5. Drill remaining holes with 11mm drill.
6. Fit bolts and plates as per diagram.
7. Tighten all bolts to torque listing below.
8. Cut out section of bumper as shown in diagram.
9. Refit bumper.

**RECOMMENDED ASSEMBLY TORQUE LISTING**

<b><u>Diameter</u></b>	<b><u>Grade 8.8 Bolt</u></b>
	<b>Nm</b>
M6	9.5
M8	21.7
M10	43.4
M12	77.3
M14	121.0
M16	189.8

# TRAILBOSS

Towbar Fitting Instructions  
To Suit MITSUBISHI LANCER SEDAN AND COUPE 9/92 ON  
SPORTS MODEL VR-X  
Part Number CL56A  
Rating 750Kg

