



Towbar Fitting Instructions
To Suit MITSUBISHI OUTLANDER 4X4 2003 ON
Part Number CL67
Rating 1200Kg

IMPORTANT: *Any holes drilled in vehicles must be covered with suitable rust Prevention paint on all bare metal surfaces.*

1. Ensure all hardware items have been included.
2. Remove rear shipping hooks and cross brace then discard.
3. Remove rear muffler from last 3 rubber hangers.
4. Remove muffler heat shield.
5. Lift tow bar up to sub frame and align with tapped holes.
6. Fit 2 horizontal bolts, spring & flat washers supplied loosely.
7. Tighten horizontal bolts first so as to align vertical holes in sub frame.
8. Fit remaining bolts, spring washers & flat washers.
9. Tighten all bolts to torque listing.
10. Re install heat shield and rear muffler.

RECOMMENDED ASSEMBLY TORQUE LISTING

<u>Diameter</u>	<u>Grade 8.8 Bolt</u>
	<u>Nm</u>
M6	9.5
M8	21.7
M10	43.4
M12	77.3
M14	121.0
M16	189.8

Towbar Fitting Instructions
To Suit MITSUBISHI OUTLANDER 4X4 2003 ON
Part Number CL67
Rating 1200Kg

