

TRAILBOSS

Towbar Fitting Instructions To Suit MITSUBISHI VERADA V6 SEDAN 7/91-ON Part Number CL72 Rating 1200Kg

1. Ensure all hardware items have been included.
2. Remove spare wheel.
3. Lift towbar in position and support it with a jack.
4. Fit four bolts supplied, into threaded holes in chassis side members.
5. Using holes in towbar as guides, drill 10mm clearance hole into boot.
6. Open up in top panel only to receive spacers.
7. Fit loose plate, bolts and spacers.
8. Tighten all bolts to torque listing below.
9. Replace spare wheel.

RECOMMENDED ASSEMBLY TORQUE LISTING

<u>Diameter</u>	<u>Grade 8.8 Bolt</u>
	<u>Nm</u>
M6	9.5
M8	21.7
M10	43.4
M12	77.3
M14	121.0
M16	189.8

