



Fitting Instructions: DAT090

Vehicle: Nissan Dualis (2007 – ON)

Nissan Qashqai (2014 - ON)

Note: Does not fit the Nissan Dualis +2 model

Towing Capacity: 1400kg / 120kg

Fitting Kit:

- 2x Large Plates with 2 square holes in line (On Bar)
- 4x 4" x 1/2" Cup Head Bolts, Flat & Star Washers, Nuts.
- 4x 65mm Crush Tubes
- 1 x 12mm Tapped plate
- 1x 12 x 40mm fine thread bolt
- 1x Small square hole plate (MAZ059)
- 1x D' shackle
- 2x Towbar Rating Labels

1.	Expose floor pan in luggage area drivers & passenger sides by removal of foam inserts / trim. Note: On Nissan Dualis wiring on both sides passes in close proximity to holes to be drilled in step 5. <u>ON QASHQAI MODELS WITH TIE DOWN HOOK (bumper has square plug on drivers side) SEE INSTRUCTION # 8</u>
2.	Remove exhaust rubbers from muffler allowing it to drop away from the vehicle.
3.	On Nissan Dualis only - find centre line of bumper, cut 70mm each side of centre & up 25mm from base of bumper.
4.	Place towbar to underside of vehicle, round holes on towbar arms align with raised holes on chassis rails. Hold in place with jack.
5.	Slotted holes in towbar will align with existing holes in vehicle chassis. Refer warning step 1 - Drill 1/2" holes via towbar slotted holes into luggage area of vehicle.
6.	In luggage area of vehicle, open out holes to accommodate crush tubes. Feed cup head bolts via plates, crush tubes into chassis & towbar arms.
7.	Undercar fit flat / star washers & nuts but do not tighten at this stage. Check towbar alignment - refer step 4. Ensure wiring detailed in step 1 is clear of plates.
8.	Remove rear bumper, fit towbar as per instructions 1 - 7 excepting rear most hole drivers side, drill 12mm hole via round hole in towbar side arm drivers side only through base of chassis only, fit tapped plate supplied into exposed chassis end then fit 12mm bolts supplied. Fit remaining long bolt complete with small square hole plate and tube via in boot drilled hole, large plate not required. Tighten all bolts.
9.	Replace exhaust rubbers.
10.	Replace trim removed in step 1.
11.	Apply Towbar Rating Labels to driver's side door sill <u>and</u> non-removable part of the towbar.