



Towbar Fitting Instructions  
To Suit NISSAN PULSAR SEDAN 8/95-6/00  
Part Number DS76A  
Rating 900Kg

1. Ensure all hardware items have been included.
2. Remove and discard shipping hook on passenger side.
3. Fit three bolts on wires through end of chassis and into existing holes on drivers side.
4. Lift towbar into position drivers side first and then passenger side.
5. Fit bolts and washers. Do not tighten.
6. Fit remaining nuts and washers on drivers side.
7. Tighten all bolts to torque listing below.

**RECOMMENDED ASSEMBLY TORQUE LISTING**

<u>Diameter</u>	<u>Grade 8.8 Bolt</u>
	<b>Nm</b>
M6	9.5
M8	21.7
M10	43.4
M12	77.3
M14	121.0
M16	189.8

# TRAILBOSS

Towbar Fitting Instructions  
To Suit NISSAN PULSAR SEDAN 8/95-6/00  
Part Number DS76A  
Rating 900Kg

