



Towbar Fitting Instructions  
To Suit NISSAN NAVARA D22 4WD WITHOUT BUMPER 86-ON  
Part Number DS92  
Rating 1250Kg

1. Ensure all hardware items have been included.
2. Lift towbar up into position locating most rearward holes in towbar side arms with large holes in bottom face of chassis.
3. Fit bolts and loose plates.
4. Using two most forward holes in towbar side arms as a guide drill remaining two holes and fit loose plates, bolts, spring washers and nuts.
5. Tighten all bolts to torque listing below.

**RECOMMENDED ASSEMBLY TORQUE LISTING**

<b><u>Diameter</u></b>	<b><u>Grade 8.8 Bolt</u></b>
	<b>Nm</b>
M6	9.5
M8	21.7
M10	43.4
M12	77.3
M14	121.0
M16	189.8

Towbar Fitting Instructions  
To Suit NISSAN NAVARA D22 4WD WITHOUT BUMPER 86-ON  
Part Number DS92  
Rating 1250Kg

