



Towbar Fitting Instructions
To Suit FORD AU FAIRLANE 2/99-ON
Part Number FD109A
Rating 1600Kg

1. Ensure all hardware items have been included.
2. Remove spare wheel.
3. Remove bumper bar.
- 3a. Remove four plastic trim buttons and one 8mm nut at each wheel arch.
- 3b. From inside boot fold forward rear 3 trims to expose two 8mm nuts one each side and remove.
- 3c. From under vehicle drill out two pop rivets holding support brace to spare wheel well.
- 3d. Remove number plate to have access to 8mm bolt before freeing bumper bar.
- 3e. Remove bumper.
4. Remove support brace and retain hardware .
5. Fit towbar to support brace mounting points using retained hardware semi tight.
6. Fit support arms using hardware supplied.
7. Tighten all bolts to torque listing below.
8. Refit bumper bar using hardware supplied to refit bumper support brace to spare wheel well.
9. Refit spare wheel.

RECOMMENDED ASSEMBLY TORQUE LISTING

<u>Diameter</u>	<u>Grade 8.8 Bolt</u>
	Nm
M6	9.5
M8	21.7
M10	43.4
M12	77.3
M14	121.0
M16	189.8

Towbar Fitting Instructions
To Suit FORD AU FAIRLANE 2/99-ON
Part Number FD109A
Rating 1600Kg

