

**BORONIA TOWBARS
1/12 EDINA RD
FERNTREE GULLY
VIC 3156
(03) 9752 2642**

**FOR 59 FITTING INSTRUCTIONS
EF-EL FALCOLN SEDAN 1994 – 1998
TOWING CAPACITY 1600kg**

REMOVE REAR BUMPER BAR AND BUMPER COVER PLATE.
REMOVE SPARE WHEEL AND TWO RUBBER GROMMETS IN SPARE WHEEL FLOOR.
REMOVE PLASTIC PANELLING IN BOOT.
MOUNT TOWBAR TO REAR OF VEHICLE VIA EXISTING HOLES IN REAR PANEL USING FOUR BOLTS SUPPLIED AND TIGHTEN.
FIT TWO WIRED BOLTS SUPPLIED VIA EXISTING HOLES ADJACENT TO TOWBAR LUG AREA AND TIGHTEN.
FIT REMAINING TWO BOLTS COMPLETE WITH PLATES SUPPLIED VIA HOLES IN SPARE WHEEL WELL AND THROUGH TOWBAR TAIL PLATE AND TIGHTEN.
REFIT REAR BUMPER BAR, SPARE WHEEL AND PLASTIC PANELLING.

NOTE:

A SMALL SECTION CAN BE CUT FROM BUMPER BAR UNDER CAR SIDE DIRECTLY BELOW THE LUG HOLDING BOLT (TOWARDS FRONT OF VEHICLE) THIS THEN ALLOWS THE TOW LUG TO BE EASILY REMOVED AND THE BUMPER COVER PLATE CAN THEN BE REFITTED IF REQUIRED THUS CONCEALING THE ENTIRE TOWBAR.

FITTING KIT:

4 – 1 ½ x 3/8 WIRED BOLTS, NUTS, S/W & F/W
2 – 1 ¼ x 3/8 WIRED BOLTS, NUTS, S/W & F/W
2 – 1 ½ x 3/8 BOLTS, NUTS, S/W & F/W
2 – 1 ½ x 3 x 3/8 PLATES
1 – DEE SHACKLE