

**BORONIA TOWBARS P/L**  
**1/12 EDINA RD**  
**FERNTREE GULLY**  
**VIC 3156**  
**PH: (03) 9752 2642**  
**FAX: (03) 9752 2575**

**FOR62 FITTING INSTRUCTIONS**  
**AU FALCON SEDAN**  
**TOWING CAPACITY 1600KG**

REMOVE SPARE WHEEL  
DRILL POP RIVET UNDER CAR - BUMPER.  
REMOVE INTERIOR BOOT LINING.  
REMOVE AIR DUCT PASSENGER SIDE REAR GUARD, TO ACCESS BUMPER  
HOLDING BOLT.  
REMOVE REAR BUMPER.  
REMOVE CENTRE METAL SUPPORT & DISCARD.  
FIT TOWBAR INTO POSITION USING ORIGINAL BOLTS & NUTS. DO NOT  
TIGHTEN AT THIS STAGE.  
FIT WIRE TO BOLTS SUPPLIED THROUGH REAR PANEL & TOWBAR, FIT NUTS  
& TIGHTEN.  
TIGHTEN ALL OTHER BOLTS.  
REFIT REAR BUMPER BAR.  
REFIT AIR DUCT & BOOT LINING.  
REFIT SPARE WHEEL.

**FITTING KIT:**

2 - 10mm x 45mm BOLTS ON WIRE, NUTS, STAR & FLAT WASHERS.  
1 - D SHACKLE.