

**Boronia Towbars**  
**1/12 Edina rd,**  
**Ferntree Gully**  
**Vic 3156**  
**Ph: (03) 9752 2642**

**FOR61/FOR65 FITTING INSTRUCTIONS:**  
Transit van.

REMOVE REAR BUMPER BAR HOLDING BOLTS – (4).  
PLACE TOWBAR INTO POSITION – REAR SUBFRAME, REFIT BUMPER  
HOLDING BOLTS VIA TOWBAR.  
TIGHTEN ALL BOLTS.

**FITTING KIT:**

1 – DEE SHACKLE.