



Fitting Instructions: GW03H

Vehicle: GWM CANNON XSR UTE

Towing Capacity: 3000kg / 300kg

Fitting Kit:

- 6x 120 x 12mm Bolts & flange nuts.
- 2x 80 x 12mm Bolts star and flat washers.
- 2x D-Shackles.

- 2x Towbar Rating Labels.

1.	Remove silver bumper holding bolts (3 either side of chassis).
2.	Fit towbar into position, aligning side plate holes with bolts removed.
3.	Fit 120 x 12mm bolts (3 either side) do not tighten at this stage.
4.	Fit 80 x 12mm bolts to centre Towbar support tags, Which will align with centre crossmember holes.
5.	Tighten all bolts.
7.	Apply Towbar Rating Labels to driver's side door sill <u>and</u> non-removable part of the towbar.