



Towbar Fitting Instructions  
To Suit HONDA ODYSSEY  
Part Number HN38  
Rating 720Kg

1. Ensure all hardware items have been included.
2. Fold rear seat forward.
3. Remove rear plastic trim to enable luggage compartment carpet to be raised.
4. From under vehicle remove four bumper clips. (refer to diagram)
5. From under vehicle using rearward most hole in centre reinforcing plate as guide, drill top layer out to 11mm. (refer to diagram)
6. Enlarge hole in top layer to accommodate spacer tube.
7. Fit loose plate coach bolt and spacer tube.
8. Position tail of towbar onto bolt and fit nut semi tight.
9. Making sure rear mounting plate is up against metal bumper insert and square to vehicle, tighten nut to torque specifications.
10. Either remove bumper bar or, with the aid of another person hold bumper edge out of the way drill four 11mm holes into metal bumper insert, by using towbar holes as guides.
11. Fit tapped plates, bolts etc. as per diagram.
12. Tighten all bolts to torque specifications listed below.
13. Refit trims and carpet mouldings.

**RECOMMENDED ASSEMBLY TORQUE LISTING**

<b><u>Diameter</u></b>	<b><u>Grade 8.8 Bolt</u></b>
	<b>Nm</b>
M6	9.5
M8	21.7
M10	43.4
M12	77.3
M14	121.0
M16	189.8

# TRAILBOSS

Towbar Fitting Instructions  
To Suit HONDA ODYSSEY  
Part Number HN38  
Rating 720Kg

