

**BORONIA TOWBARS  
1/12 EDINA RD  
FERNTREE GULLY  
VIC 3156  
(03) 9752 2642**

**HOL14H/17H & HOL41/46 FITTING INSTRUCTIONS:  
RODEO 2003 –**

**HOL41/46 FITMENT:**

MOUNT TOWBAR TO REAR SUBFRAME EXISTING HOLES USING 10mm BOLTS SUPPLIED COMPLETE WITH SPRING & FLAT WASHERS. TIGHTEN.

**HOL14H/17H FITMENT:**

REMOVE REAR BUMPER BAR IF FITTED.

MOUNT TOW HITCH TO REAR SUB FRAME EXISTING HOLES USING 10mm BOLTS SUPPLIED COMPLETE WITH SPRING & FLAT WASHERS THEN TIGHTEN.

FIT 12mm BOLTS ON WIRE THROUGH EXISTING HOLE IN SIDE OF SUBFRAME (ONE EITHER SIDE) WHICH ALIGNS WITH TOW HITCH, FIT SPRING & FLAT WASHERS THEN NUTS – TIGHTEN. (ON CAB CHASSIS HOLES MUST BE DRILLED – 12mm)..

CHECK ALL BOLTS FOR TIGHTNESS.

REFIT REAR BUMPER BAR.

(ON SHORT TRAY MODEL, POSITION TOWBAR/HITCH TOWARDS FRONT OF VEHICLE ALIGNING WITH EXISTING SEMI HOLES, DRILL THESE OUT TO 10mm THEN FIT TOWBAR VIA THESE HOLES USING BOLTS SUPPLIED, TIGHTEN).

**FITTING KIT**

**(HOL41)**

4 – 10 x 35mm FINE THREAD BOLTS, NUTS, SPRING & FLAT WASHERS

1 – DEE SHACKLE

**(HOL14H)**

4 – 10 x 35mm FINE THREAD BOLTS, NUTS, SPRING & FLAT WASHERS

4 – 10mm FLAT WASHERS

2 – 12 x 40mm BOLTS ON WIRE, SPRING, FLAT WASHERS & NUTS

2 – DEE SHACKLES

**\* WIRING HARNESS AVAILABLE FOR THIS TOWBAR\***