

**BORONIA TOWBARS  
1/12 EDINA RD  
FERNTREE GULLY  
VIC 3156  
(03) 9752 2968**

A.C.N. 004 883 336

**HOL 22 FITTING INSTRUCTIONS  
RODEO UTE 1981-2002  
RATED TOWING CAPACITY 1000kg**

FIT TOWBAR UP TO REAR CHASSIS.

FIT BOLTS AND PLATES THROUGH CHASSIS AND TOWBAR, THEN FIT NUTS AND SPRING WASHERS.

DRILL 10mm HOLES VIA TOWBAR THROUGH CHASSIS.

FIT BOLTS AND PLATES DOWN THROUGH CHASSIS AND TOWBAR, COMPLETE WITH NUTS AND SPRING WASHERS.

TIGHTEN ALL BOLTS

**FITTING KIT:**

4 – 12 x 40mm FINE THREAD BOLTS, NUTS, SPRING AND FLAT WASHERS

2 – 1 ½ x 3/8 BOLTS, NUTS, SPRING AND FLAT WASHERS

4 – 1 ½ x 3 x ½ HOLE PLATES

2 – 1 ½ x 3 x 3/8 HOLE PLATES

1 – DEE SHACKLE