

**BORONIA TOWBARS  
1/12 EDINA RD  
FERNTREE GULLY  
VIC 3156  
(03) 9752 2968**

A.C.N. 004 883 336

**HOL33 - 36 FITTING INSTRUCTIONS**  
**VN – VS COMMODORE SEDAN IRS V6 / V8 & STATESMAN 10/91 – 8/97**  
**TOWING CAPACITY 1250 KG**

REMOVE TANK STRAP BOLT UNDERCAR.

REMOVE TWO DIFFERENTIAL BOLTS WHICH CORRESPOND WITH  
TOWBAR TAIL PLATE HOLES.

REMOVE BOOT MAT.

FIT TOWBAR UP TO VEHICLE VIA TANK STRAP BOLT. FIT NUT AND  
TIGHTEN.

FIT 8mm BOLTS SUPPLIED VIA TOWBAR TAIL PLATE AT DIFFERENTIAL  
INTO EXISTING HOLES AND TIGHTEN.

DRILL ½“ HOLES VIA TOWBAR INTO BOOT AREA.

OPEN TOP HOLES TO ALLOW TUBES TO FIT, FIT LARGE PLATES C/W  
BOLTS AND TUBES IN BOOT AND THROUGH TOWBAR. FIT NUTS AND  
C/W WASHERS - TIGHTEN.

**FITTING KIT:**

2 – 3 x ½ BOLTS, NUTS AND SPRING WASHERS

2 – 8 x 35mm BOLTS, SPRING WASHERS AND FLAT WASHERS

2 – ½” CLEARANCE TUBES

2 – LARGE PLATES

1 - DEE SHACKLE