

**Boronia Towbars
1/12 Edina Rd
Ferntree Gully
Vic 3156
(03) 9752 2642**

**HOL38 FITTING INSTRUCTIONS:
HOLDEN ASTRA.**

REMOVE INTERIOR BOOT MAT.

MOUNT TOWBAR TO SUB FRAME, HOLDING FIRM WITH JACK.

DRILL (10mm) ALL HOLES, THE TWO MOST REAR HOLES, (ONE EITHER SIDE OF SUB FRAME) DRILL THROUGH SINGLE PANEL ONLY, THE FOUR OTHER HOLES TO BE DRILLED (10mm) THROUGH DUAL SUBFRAME INTO BOOT AREA.

FIT WIRED TAPPED PLATES SUPPLIED INTO SUB FRAME & ALIGN WITH TWO MOST REAR HOLES, FIT 10mm BOLTS COMPLETE WITH FLAT & SPRING WASHERS SUPPLIED & TIGHTEN.

DRILL (10mm) REMAINING (4) HOLES VIA TOWBAR INTO BOOT AREA. OPEN IN BOOT DRILLED HOLES TO ACCEPT TUBES SUPPLIED, FIT BOLTS TO PLATES THEN TUBES & FIT VIA DRILLED HOLES, TIGHTEN USING NUTS SUPPLIED COMPLETE WITH SPRING & FLAT WASHERS.

FITTING KIT:

- 2 – 10 x 35mm BOLTS, SPRING & FLAT WASHERS
- 2 – 10mm TAPPED PLATES ON WIRE
- 4 – 31/2 x 3/8 BOLTS, NUTS, SPRING & FLAT WASHERS
- 4 – 23/8 x 1/2 TUBES
- 4 – 10mm HOLE PLATES
- 1 - DEE SHACKLE