

BTA Towbars

Australia's Towing Equipment Specialist



Fitting Instructions: HON02

Vehicle: HONDA ACCORD EURO SEDAN 06/2003 – 02/2008

Towing Capacity: 1200kg

Fitting Kit:

- 1x 2 slotted hole plate
- 6x M8 x 35 bolts, spring washers
- 12x M8 flat washers
- 2x M10 x 45 bolts, nuts, star & flat washers
- 2x M10 flat washers
- 1x D shackle
- 2x Towbar Rating Labels

1.	Remove bumper.
2.	Remove & discard crash support panel.
3.	Mount towbar to rear of car using M8 x 35 bolts, flat & star washers (3 each side). Centralise towbar on car & tighten all bolts.
4.	Feed 2 slotted hole plate through tie down hook under car aligning with slotted holes in towbar.
5.	Feed M10 x 45 bolts via flat washer, towbar, slotted hole plate & fit flat / star washers & nuts (2). Tighten all bolts.
6.	Check all bolts for tightness.
7.	Bumper cut required prior to refitting bumper. Locate centre of bumper, cut 45mm each side of centre & 30mm up from edge of bumper.
8.	Apply Towbar Rating Labels to driver's side door sill <u>and</u> non-removable part of the towbar.