

BORONIA TOWBARS
1/12 EDINA RD
FERNTREE GULLY
VIC 3156
(03) 9752 2642.

HON1 & 1H FITTING INSTRUCTIONS:
CRV WAGON

REMOVE REAR MUFFLER.
REMOVE SPARE WHEEL & JACK.
MOUNT TOWBAR TO CENTRE TIE DOWN HOOK USING 2 x ½ BOLT COMPLETE WITH PLATE, SPRING, FLAT WASHER & NUT, TIGHTEN.
DRILL FOUR 10mm HOLES VIA TOWBAR SIDE ARMS THROUGH BASE OF CHASSIS, FEED TAPPED PLATES INTO CHASSIS, ALIGN WITH DRILLED HOLES, FIT 10mm BOLTS SUPPLIED COMPLETE WITH SPRING & FLAT WASHERS, TIGHTEN.
DRILL (10mm) TWO REMAINING HOLES VIA TOWBAR SIDE ARMS THROUGH SPARE WHEEL CARRIER, FIT 3/8" BOLTS SUPPLIED COMPLETE WITH PLATES, NUTS, SPRING & FLAT WASHERS, TIGHTEN.
CHECK ALL BOLTS FOR TIGHTNESS.
REFIT REAR MUFFLER.
REFIT SPARE WHEEL.

*ELECTRICAL WIRING CAN BE FOUND BEHIND PASSENGER SIDE REAR SPEAKER.
PLUG IN WIRING HARNESSSES ARE AVAILABLE FOR THIS VEHICLE.*

FITTING KIT:

4 – 10 x 35mm FINE THREAD BOLTS, SPRING & FLAT WASHERS.
4 – 10mm TAPPED PLATES ON WIRE.
2 – 11/2 x 3/8 BOLTS, NUTS & SPRING WASHERS.
1 – 2 x ½ BOLT, NUT, SPRING & FLAT WASHER.
2 – STANDARD 10mm HOLE PLATES.
1 – 12mm OFFSET/ANGLED HOLE PLATE.
1 – DEE SHACKLE.