

BORONIA TOWBARS P/L
1/12 EDINA RD
FERNTREE GULLY
VIC 3156
PH: (03) 9752 2642

HYU3H FITTING INSTRUCTIONS
HYUNDAI TUSCON 06- / KIA SPORTAGE 06-

REMOVE DRIVERS SIDE SHIPPING HOOK – DISCARD.
REMOVE REAR EXHAUST RUBBERS, ALLOWING REAR MUFFLER TO DROP.
MARK CENTRE OF REAR BUMPER, CUT 45mm EITHER SIDE OF CENTRE AND UP
20mm (SPORTAGE) & 45mm (TUSCON).
MOUNT TOW HITCH TO REAR CHASSIS USING 10mm BOLTS SUPPLIED
COMPLETE WITH SPRING & FLAT WASHERS- TIGHTEN.
REFIT REAR MUFFLER.

Note:

2007 Tucson requires bumper cut 120mm up from base

FITTING KIT:

6 – 10 x 35 FINE THREAD BOLTS, SPRING & FLAT WASHERS