

**BORONIA TOWBARS
1/12 EDINA ROAD
FERNTREE GULLY
VIC 3156
(03)9752 2642**

**HYU14 FITTING INSTRUCTIONS:
GETZ HATCH.**

REMOVE 12mm BOLTS FROM REAR SUB FRAME. DISCARD
MOUNT TOWBAR TO SAME AREA USING 12mm BOLTS SUPPLIED COMPLETE WITH
SPRING & FLAT WASHERS.
TIGHTEN BOLTS.
RECHECK ALL BOLTS FOR TIGHTNESS.

NOTE

Some models require bumper cutting. Cut the bumper 80 x 80 up from bottom of bumper in the towlug area.

FITTING KIT:

4 – 12 x 40mm FINE THREAD BOLTS, SPRING & FLAT WASHERS.
1 – DEE SHACKLE