

**BORONIA TOWBARS
1/12 EDINA ROAD
FERNTREE GULLY
VIC 3156
(03) 9752 2642**

HYU17 FITTING INSTRUCTIONS.
ACCENT SEDAN/HATCH 08/06 ON.

REMOVE REAR MUFFLER.

MOUNT TOWBAR TO REAR CHASSIS VIA EXISTING HOLES, USING 12mm BOLTS SUPPLIED, COMPLETE WITH SPRING AND FLAT WASHERS.

FIT 16mm BOLT VIA TOWBAR CENTRE TIE DOWN THEN PLATE, SPRING WASHER AND NUT. – TIGHTEN.

CHECK ALL BOLTS FOR TIGHTNESS

REFIT REAR MUFFLER

FITTING KIT:

4 – 12 X 40 FINE THREAD BOLTS, SPRING & FLAT WASHERS.

1 – 16 X 50 BOLT, NUT AND SPRING WASHERS.

1 – 3 x 2 x 16mm HOLE PLATE

1 – DEE SHACKLE.