



**Fitting Instructions: HYU018**

- Vehicle:** Hyundai i30 Hatch (2007 – on)
- Towing Capacity:** 1200kg
- Fitting Kit:**
- 4x 10 x 35 fine thread bolts, spring & flat washers
  - 1x 'D' shackle
  - 2x Towbar Rating Labels

1.	Remove plastic cover plate under rear bumper.
2.	Remove plastic clip from bumper centre support at base of bumper, rotate bumper centre support approximately 50mm to either side, cut centre tag from base of bumper.
3.	Remove tie down hooks.
4.	Mount towbar to existing holes using 10mm bolts.
5.	Tighten all bolts.
6.	Apply Towbar Rating Labels to driver's side door sill <u>and</u> non-removable part of the towbar.