

**BORONIA TOWBARS P/L
1/12 EDINA RD
FERNTREE GULLY
VIC 3156
(03) 9752 2642**

**HYU2H FITTING INSTRUCTIONS
HYUNDAI SANTA FE.**

REMOVE REAR TIE DOWNS & DISCARD.

REMOVE SPARE WHEEL.

USING 10mm (6) BOLTS SUPPLIED COMPLETE WITH SPRING & FLAT WASHERS, MOUNT TOWBAR TO EXISTING HOLES IN REAR CHASSIS, THEN TIGHTEN.

DRILL (10mm) HOLE VIA CENTRE UPRIGHT INTO BACK METAL PANEL OF REAR BUMPER BAR. FIT WIRE TO BOLT SUPPLIED INTO REAR PANEL & THROUGH DRILLED HOLE, FIT NUT WITH SPRING & FLAT WASHER, THEN TIGHTEN.

CHECK ALL BOLTS FOR TIGHTNESS.

REFIT SPARE WHEEL.

FITTING KIT:

6 – 10 x 35mm BOLTS, SPRING & FLAT WASHERS

1 – 11/4 x 3/8 BOLT ON WIRE, NUT, SPRING & FLAT WASHER.

2 – DEE SHACKLES.