

**BORONIA TOWBARS  
1/12 EDINA RD  
FERNTREE GULLY  
VIC 3156  
(03) 9752 2642**

**JEEP2H FITTING INSTRUCTIONS:  
WRANGLER.**

REMOVE REAR TIE DOWNS & DISCARD  
MOUNT TOW HITCH TO REAR SUB FRAME USING TIE DOWN HOLDING BOLTS, FIT 12mm  
BOLT SUPPLIED TO REMAINING HOLE – TIGHTEN.

FIT REMAINING BOLTS VIA TOW HITCH AND SUB FRAME FIT PLATES SPRING & FLAT  
WASHERS, NUTS THEN TIGHTEN.

**FITTING KIT:**

2 – 12 x 40mm BOLTS, NUTS, SPRING & FLAT WASHERS  
2 – 4 x ½ BOLTS, NUTS, SPRING & FLAT WASHERS  
2 – ½” HOLE PLATES.  
2 – DEE SHACKLES.

**NOTE: TOW HITCH WILL NOT FIT VEHICLES FITTED WITH CHROME PIPE REAR  
BUMPER. (THIS IS A JEEP OPTIONAL EXTRA).**