

**BORONIA TOWBARS P/L
1/12 EDINA RD
FERNTREE GULLY
VIC 3156
(03) 9752 2642**

**KIA5 FITTING INSTRUCTIONS
PREGIO VAN 2004 –**

REMOVE SPARE WHEEL

FIT FOUR 1/12 x 3/8 BOLTS WITH FLAT WASHERS SUPPLIED TO EXISTING HOLES AT REAR OF SPRING SHACKLE MOUNTING AREA.

PLACE TOWBAR INTO POSITION ALIGNING WITH BOLTS FITTED, FIT FLAT & SPRING WASHERS WITH NUTS – TIGHTEN.

DRILL (10mm) HOLES (2) VIA TOWBAR UPRIGHTS, FIT (2) 10mm TAPPED PLATES ON WIRE VIA EXISTING LARGE HOLE, ALIGN WITH DRILLED HOLES, FIT 10mm BOLTS COMPLETE WITH SPRING & FLAT WASHERS – TIGHTEN.

FIT WIRE TO BOLT SUPPLIED VIA HOLE IN SIDE OF PASSENGER SIDE CHASSIS THEN THROUGH ORIGINAL HOLE IN BASE OF CHASSIS & FINALLY THROUGH TOWBAR MOUNTING BRACKET HOLE, FIT NUT WITH SPRING & FLAT WASHER – TIGHTEN.

CHECK ALL BOLTS FOR TIGHTNESS.

REFIT SPARE WHEEL.

FITTING KIT:

- 4 – 11/2 x 3/8 BOLTS, NUTS & SPRING WASHERS.
- 1 – 11/2 x 3/8 BOLT ON WIRE, NUT & SPRING WASHER.
- 2 – 10 x 35mm FINE BOLTS & SPRING WASHERS.
- 2 – 10mm TAPPED PLATES ON WIRE.
- 11- 10mm FLAT WASHERS.
- 1 – DEE SHACKLE.