

BTA Towbars

Australia's Towing Equipment Specialist



Fitting Instructions: LDV01

Vehicle: V80 Van 2013 - on

Towing Capacity: 1200 / 120Kg

Fitting Kit:

- 1 - 16 x 60mm with spring washers
- 1 - 3 x 2 16mm hole plate
- 3 - 12 x 40mm course thread bolts
- 1 – Dee Shackles
- 2 – Towbar rating labels

1.	Mount towbar to drivers side of vehicle using 12mm bolts supplied.
2.	Mount towbar to passengers side of vehicle tie down hook using 16mm bolt via plate supplied.
3.	Tighten all bolts.
4.	Apply Towbar Rating Labels to driver's side door sill <u>and</u> non-removable part of the towbar.