

TRAILBOSS

Towbar Fitting Instructions To Suit FORD TELSTAR/MAZDA 626 92-ON Part Number MA50 Rating 920Kg

1. Ensure all hardware items have been included.
2. Remove back panel trim.
3. Remove shipping hook on passenger side back panel.
4. Use two holes each side on inner side of sub frames two in boot, two from under car.
5. Feed towbar up on driver's side up over exhaust.
6. Line up with holes previously described and support with jack.
7. Fit bolts and plates supplied.
8. Tighten all bolts to torque listing below.
9. Refit boot panel trim.

RECOMMENDED ASSEMBLY TORQUE LISTING

<u>Diameter</u>	<u>Grade 8.8 Bolt</u>
	Nm
M6	9.5
M8	21.7
M10	43.4
M12	77.3
M14	121.0
M16	189.8

