



Towbar Fitting Instructions
To Suit MAZDA PREMACY 2/01-on
Part Number MA64
Rating 720Kg

1. Ensure all hardware items have been included.
2. Remove spare wheel.
3. Remove rear muffler from two rear most rubber hangers.
4. Remove rubber grommet from spare wheel well.
5. Using wedge tool provided, open out third large hole from rear of vehicle in chassis rail each side, so as tapped plates on wire fit freely.
6. Fit towbar to align with chassis holes and fit central loose plate and coach bolt semi tight.
7. Fit all tapped plates through hole enlarged in step 5 to align with towbar and chassis.
8. Fit all bolts supplied and tighten as per torque listing below.
9. Refit spare wheel.
10. Refit rear muffler onto rubber hangers.

RECOMMENDED ASSEMBLY TORQUE LISTING

<u>Diameter</u>	<u>Grade 8.8 Bolt</u>
	Nm
M6	9.5
M8	21.7
M10	43.4
M12	77.3
M14	121.0
M16	189.8

TRAILBOSS

Towbar Fitting Instructions
To Suit MAZDA PREMACY 2/01-on
Part Number MA64
Rating 720Kg

