

**BORONIA TOWBARS
1/12 EDINA ROAD
FERNTREE GULLY
VIC 3156
(03) 9752 2642**

**MAZ 39 FITTING INSTRUCTIONS
E SERIES MID / LWB SINGLE REAR WHEEL VAN 1984-ON
TOWING CAPACITY 1000KG**

REMOVE 4 BOLTS HOLDING BUMPER / STEP ARRANGEMENT.
PLACE TOWBAR UP TO STEP AREA, USING (10mm) BOLTS
SUPPLIED FIT VIA TOWBAR & TIGHTEN.
THE WHEELBASE OF THE VEHICLE WILL DECIDE WHERE AND
WHICH OF THE FORWARD ARM BRACKETS SHALL BE USED.
THERE WILL BE TWO (ONE ON EITHER SIDE OF CHASSIS) THAT
WILL NOT MOUNT, AGAIN THIS IS DECIDED BY THE WHEELBASE -
THIS IS NORMAL.
FIT THE REMAINING TWO BY FIRST DRILLING (10mm) HOLES VIA
TOWBAR INTO BOOT AREA, FIT BOLTS, PLATES AND SLEEVES
SUPPLIED - TIGHTEN.
CHECK ALL BOLTS FOR TIGHTNESS.

FITTING KIT:

- 4 – 10 x 35mm FINE THREAD BOLTS & SPRING WASHERS
- 2 – 5 ½ x 3/8 BOLTS, NUTS & SPRING WASHERS
- 2 – 4 x ½ SLEEVES
- 2 – 3 x 1 ½ x 3/8 HOLE PLATES
- 1 – DEE SHACKLE