

**Boronia Towbars
1/12 Edina Road
Ferntree Gully
Victoria 3156
Ph: (03) 97522642.**

MAZ3H Fitting instructions:
B Series / Courier Ute & Tray with Bumper 03/99 – on
Towing Capacity 3000kg Max

REMOVE REAR BUMPER BAR
MOUNT TOWHITCH TO REAR SUBFRAME (FURTHEST HOLE FORWARD) USING BOLTS ON WIRE SUPPLIED, COMPLETE WITH NUTS, SPRING AND FLAT WASHERS.
USE SPACER BLOCKS TO SPACE OUT BUMPER IRONS, DISCARD ORIGINAL BOLTS AND FIT 10mm BOLTS SUPPLIED, TIGHTEN.
REFIT BUMPER.
TIGHTEN ALL BOLTS.

Note

Towing Capacity varies between models.
New Mazda BT50 2wd is only rated to 1800Kg but equivalent 4wd model is rated at 3000kg.
Please refer Manufacturers instructions when determining tow ratings.

FITTING KIT

4 – 12 x 40mm **MEDIUM** THREAD BOLTS, SPRING & FLAT WASHERS
2 – 12 x 40mm FINE THREAD BOLTS ON WIRE, NUTS, SPRING & F/W
4 – 10 x 45mm BOLTS, NUTS, STAR & FLAT WASHERS
4 – 10 x 32 x 32 SPACER BLOKES
2 – DEE SHACKLES