

**BORONIA TOWBARS P/L**  
**1/12 EDINA RD**  
**FERNTREE GULLY**  
**VIC 3156**  
**PH: (03) 9752 2642**  
**FAX: (03) 9752 2575**

**MAZ46 FITTING INSTRUCTIONS**  
**MAZDA B SERIES UTE WITH STEP**  
**TOWING CAPACITY 1000KG**

REMOVE REAR BUMPER BAR.

REFIT BUMPER BAR COMPLETE WITH TOWBAR TO ORIGINAL POSITION  
USING 12mm BOLTS SUPPLIED - TIGHTEN.

DRILL (10mm) HOLES VIA TOWBAR FORWARD ARMS THROUGH BOTTOM  
SUB FRAME, FITBOLTS & PLATES SUPPLIED- TIGHTEN.

CHECK ALL BOLTS FOR TIGHTNESS.

**FITTING KIT:**

4 - 12mm x 40mm MEDIUM THREAD BOLTS, SPRING & FLAT WASHERS.

2 - 1.1/2" x 3/8" BOLTS, NUTS, SPRING & FLAT WASHERS.

2 - 11mm HOLE PLATES.

1 - D SHACKLE.