

**BORONIA TOWBARS
1/12 EDINA RD
FERNTREE GULLY
VIC 3156
(03) 9752 2642**

**MAZ47 FITTING INSTRUCTIONS
MAZDA 323 SEDAN & HATCH BG 89 – 94**

REMOVE REAR BUMPER BAR
MOUNT TOWBAR TO REAR PANELS' EXISTING HOLES USING ONE BOLT SUPPLIED EITHER SIDE, MAKE SURE TOWBAR IS ALIGNED WITH ALL HOLES IN REAR PANEL. DRILL (10mm) HOLE VIA TOWBAR SIDE PLATE THAT DOES NOT ALIGN WITH HOLE IN BACK PANEL.
REMOVE BOLTS HOLDING TOWBAR & REFIT INTO HOLES DRILLED, FIT FLAT & SPRING WASHERS THEN TIGHTEN.
REFIT REAR BUMPER BAR.

FITTING KIT:

4 – 1/12 x 3/8 BOLTS, NUTS, SPRING & FLAT WASHERS
4 – 10mm FLAT WASHERS
1 – DEE SHACKLE.