

**BORONIA TOWBARS P/L**  
**1/12 EDINA RD**  
**FERNTREE GULLY**  
**VIC 3156**  
**PH: (03) 9752 2642**  
**FAX: (03) 9752 2575**

**MAZ51 FITTING INSTRUCTIONS**  
**MAZDA 323 / LASER SEDAN 1994 - ON**  
**TOWING CAPACITY 1000KG**

FEED TOWBAR IN BEHIND REAR BUMPER BAR.  
FIT 1.1/4" x 3/8" BOLTS SUPPLIED VIA TOWBAR & TIE DOWN HOOK -  
PASSENGER SIDE. FIT FLAT/SPRING WASHERS & NUTS - TIGHTEN.  
DRILL (10mm) HOLES VIA TOWBAR DRIVERS SIDE, FEED TAPPED PLATES  
INTO CHASSIS & ALIGN WITH DRILLED HOLES, FIT BOLTS SUPPLIED C/W  
SPRING & FLAT WASHERS - TIGHTEN.  
CHECK ALL BOLTS FOR TIGHTNESS.

**KIT FITTING:**

2 – 1.1/4" x 3/8" BOLTS, NUTS, SPRING & FLAT WASHERS.  
2 – 10mm x 35mm FINE BOLTS, SPRING & FLAT WASHERS.  
2 - 10mm TAPPED PLATES ON WIRE.  
1 - DEE SHACKLE.