

**BORONIA TOWBARS
1/12 EDINA RD
FERNTREE GULLY
VIC 3156
(03) 9752 2642**

MAZ55 FITTING INSTRUCTIONS.
323/LASER HATCH.

REMOVE SPARE TYRE.

REMOVE REAR EXHAUST RUBBERS.

FEED TOWBAR IN BEHIND REAR BUMPER BAR, ALIGN WITH TIE DOWN HOOKS.

FIT 1/14 x 3/8 BOLTS WITH SPRING & FLAT WASHERS VIA TOWBAR THEN THROUGH TIE DOWN HOOK HOLES.

TIGHTEN.

FIT 16mm BOLTS WITH SPRING & FLAT WASHERS & SQUARE PLATES VIA TIE DOWNS & TOWBARS HOLES.

TIGHTEN.

DRILL (10mm) HOLE THROUGH CENTRE HOLE IN TOWBAR BASE PLATE INTO SPARE WHEEL AREA, FIT PLATE & BOLT SUPPLIED COMPLETE WITH NUT & SPRING WASHER, TIGHTEN.

CHECK ALL BOLTS FOR TIGHTNESS.

REFIT EXHAUST RUBBERS & SPARE WHEEL.

FITTING KIT:

2 – 16 x 45mm BOLTS, NUTS, SPRING & SQUARE WASHERS.

2 – 11/4 x 3/8 BOLTS, NUTS, SPRING & FLAT WASHERS.

1 – 11/2 x 3/8 BOLT, NUT, SPRING & FLAT WASHER.

1 – 10mm HOLE PLATE

1 – DEE SHACKLE.