

**BORONIA TOWBARS P/L
1/12 EDINA RD
FERNTREE GULLY
VIC 3156
(03) 9752 2642**

**MAZ58 FITTING INSTRUCTIONS
MAZDA 6 SEDAN/HATCH (NOT MODEL WITH SKIRTS)**

REMOVE SPARE WHEEL.

REMOVE & DISCARD TWO RUBBER GROMMETS IN SPARE WHEEL CARRIER FLOOR.

MOUNT TOWBAR TO TIE DOWN HOOKS USING 16mm BOLTS SUPPLIED COMPLETE WITH SPRING WASHERS & PLATES SUPPLIED, TIGHTEN.

FIT 75 x 40 x 11mm HOLE PLATES COMPLETE WITH 1 1/4 x 3/8 BOLTS SUPPLIED, TO HOLES IN SPARE WHEEL AREA, (TOWBAR FORWARD ARM WILL ALIGN WITH THESE HOLES), FIT NUTS WITH SPRING WASHERS – TIGHTEN.

DRILL (10mm) HOLES VIA TOWBAR SIDE SUPPORT ARMS INTO BOOT AREA, FIT 1 1/2 x 3/8 BOLTS SUPPLIED COMPLETE WITH PLATES, FIT NUTS WITH SPRING WASHERS – TIGHTEN.

REFIT SPARE WHEEL.

NOTE: WIRING HARNESS AVAILABLE FOR THIS VEHICLE.

FITTING KIT:

- 2 – 16mm BOLTS, SPRING WASHERS & CUT DOWN PLATES.
- 2 – 1 1/4 x 3/8 BOLTS, NUTS, SPRING & FLAT WASHERS.
- 2 – 1 1/2 x 3/8 BOLTS, NUTS, SPRING & FLAT WASHERS.
- 2 – 75 x 75 x 11mm HOLE PLATES.
- 2 – 65 x 20 x 11mm HOLE PLATES. (OFFSET HOLE).
- 1 – DEE SHACKLE.