



Towbar Fitting Instructions
To Suit MERCEDES 300E 86-ON
Part Number MB13A
Rating 1250Kg

1. Ensure all hardware items have been included.
2. Remove spare wheel cover.
3. Remove jack.
4. Release exhaust from rear bracket.
5. Lift towbar into position, lining it up with recess in centre of bumper bar and supporting it with a jack.
6. Using a long series drill and holes in towbar as guides, drill right through into boot.
7. In the case of the four rear holes, the drill must be held perfectly straight whilst drilling through the top part of rear cross member.
8. Open up the four rear holes in top panel only to receive spacers.
9. Fit bolts, plates and spacers and tighten as per torque listing below.
10. Replace exhaust.
11. Replace jack.
12. Replace spare wheel cover.

RECOMMENDED ASSEMBLY TORQUE LISTING

<u>Diameter</u>	<u>Grade 8.8 Bolt</u>
	<u>Nm</u>
M6	9.5
M8	21.7
M10	43.4
M12	77.3
M14	121.0
M16	189.8

TRAILBOSS

Towbar Fitting Instructions
To Suit MERCEDES 300E 86-ON
Part Number MB13A
Rating 1250Kg

