

# TRAILBOSS

Towbar Fitting Instructions  
To Suit MITSUBISHI CHALLENGER 4WD 98-ON  
Part Number QTCL610A  
Rating 2270Kg

1. Ensure all hardware items have been included.
2. Remove and discard both shipping hooks.
3. Raise towbar to vehicle chassis and align side arm holes to vehicle shipping hook anchor points.
4. Insert two M12x40 bolts to support bar loosely.
5. Insert four M12x120 bolts see diagram below.
6. Tighten all bolts to torque listing below.

## RECOMMENDED ASSEMBLY TORQUE LISTING

<u>Diameter</u>	<u>Grade 8.8 Bolt</u>
	Nm
M6	9.5
M8	21.7
M10	43.4
M12	77.3
M14	121.0
M16	189.8

