



Towbar Fitting Instructions
To Suit NISSAN PATHFINDER 10/95-on
Part Number QTDS750
Rating 2000Kg

1. Ensure all hardware items have been included.
2. Remove spare wheel.
3. Unclip wiring looms and remove and discard shipping hooks and bolts from both sides.
4. Holding towbar into position bolt towbar through top hole only on each side.
5. Place packing plates one each side between towbar and chassis. Fit bolts.
6. Using towbar as a guide drill two 11mm holes through bottom of chassis only.
7. Loosening of three bumper mounting nuts on each side on chassis rail slide bumper back and slide tapped plates on wires through gap.
8. Fit bolts and washers into tapped plates.
9. Tighten bumper mounting nuts.
10. Tighten all bolts to torque specifications.
11. Refit spare wheel.

RECOMMENDED ASSEMBLY TORQUE LISTING

<u>Diameter</u>	<u>Grade 8.8 Bolt</u>
	<u>Nm</u>
M6	9.5
M8	21.7
M10	43.4
M12	77.3
M14	121.0
M16	189.8

Towbar Fitting Instructions
To Suit NISSAN PATHFINDER 10/95-on
Part Number QTDS750
Rating 2000Kg

