



Towbar Fitting Instructions
To Suit NISSAN TERRANO II 3/97-ON
Part Number QTDS760
Rating 2800Kg

1. Ensure all hardware items have been included.
2. Remove rear muffler from hanger.
3. Hold towbar up to vehicle so as holes in towbar align with holes in shipping holes. **(NOTE: Use three 3mm spacer plates if required on driver's side. Towbar manufactured width, outside of side arms, 920mm.)**
4. Fit bolts supplied and tighten making sure angles on tail arms are up against chassis rail.
5. While holding rear muffler away using holes in angles as guides drill two 11mm holes.
6. Fit bolts on wire through holes in outside of chassis rails. Fit nuts and tighten.
7. Refit muffler.
8. Tighten all bolts to torque listing below.

RECOMMENDED ASSEMBLY TORQUE LISTING

<u>Diameter</u>	<u>Grade 8.8 Bolt</u>
	<u>Nm</u>
M6	9.5
M8	21.7
M10	43.4
M12	77.3
M14	121.0
M16	189.8

