

TRAILBOSS

Towbar Fitting Instructions To Suit RANGE ROVER 5/95-ON Part Number QTRV7

Rating Max. Tow weight 4000kg Max. Tow weight with ABS 3500kg

1. Ensure all hardware items have been included.
2. Remove bumper bar (4 x self tapers at each wheel arch, 2 x wire clips on bumper slide mounts, 1 x bolt at each chassis end).
3. Align tow hitch with mounting points on vehicle, one at each chassis end and one in centre of cross member under spare wheel well.
4. Fit all bolts as per diagram and torque to listing below.
5. Refit bumper bar.

RECOMMENDED ASSEMBLY TORQUE LISTING

<u>Diameter</u>	<u>Grade 8.8 Bolt</u>
	Nm
M6	9.5
M8	21.7
M10	43.4
M12	77.3
M14	121.0
M16	189.8

