

# TRAILBOSS

Towbar Fitting Instructions  
 To Suit VOLKSWAGON TRANSPORTER CAB CHASSIS 9/94-ON  
 Part Number QTVW190  
 Rating 2000Kg  
 Ball Weight 100Kg

1. Ensure all hardware items have been included.
2. Remove and discard shipping hook from driver's side. Position towbar by sliding towbar arms into chassis cavity to align with shipping hook bolt holes.
3. Fit bolts and loose plates supplied.
4. Ensure towbar is level and tighten all bolts as per torque listing below.
5. Using remaining two holes in towbar as guides drill two 13mm holes through chassis cross member.
6. Fit loose plates and bolts supplied.
7. Tighten all bolts to torque listing below.
8. Fit lifting tube bracket supplied to existing bracket on spare wheel carrier as per diagram.
9. Towbar rating sticker to be conspicuously located on inside rear end of the driver's door

**RECOMMENDED ASSEMBLY TORQUE LISTING**

<u>Diameter</u>	<u>Grade 8.8 Bolt</u>
	Nm
M6	9.5
M8	21.7
M10	43.4
M12	77.3
M14	121.0
M16	189.8

