

BORONIA TOWBARS P/L
1/12 EDINA RD
FERNTREE GULLY
VIC 3156
PH: (03) 9752 2642
FAX: (03) 9752 2575

SUB2A FITTING INSTRUCTIONS
SUBARU TOURING WAGON JF20 4WD 1980 - 84
TOWING CAPACITY 950KG

SUB2A FITTING INSTRUCTIONS SUBARU TOURING WAGON JF20 4WD 1980 - 84 TOWING CAPACITY 950KG
REMOVE TIE DOWNHOOKS FROM REAR SUBFRAMF, PLACE TOWBAR UP TO BRACKETS AT SUB FRAME AREA & FIT BOLTS SUPPLIED.
TIGHTEN.
DRILL (10mm) HOLES VIA TOWBAR SIDE ARMS & FIT WIRE TO BOLTS SUPPLIED INTO SUB FRAME & THROUGH TOWBAR.
TIGHTEN.
CHECK ALL BOLTS FOR TIGHTNESS.

FITTING KIT:

2 - 1.1/4" x 3/8" BOLTS, NUTS, SPRING & FLAT WASHERS.
2 - 1.1/4" x 3/8" WIRED TO BOLTS SPRING & FLAT WASHERS.
4 - 8mm x 35mm BOLTS, SPRING & FLAT WASHERS.
1 - D SHACKLE.