

BORONIA TOWBARS P/L
1/12 EDINA RD
FERNTREE GULLY
VIC 3156
PH: (03) 9752 2642
FAX: (03) 9752 2575

SUB6 FITTING INSTRUCTIONS
SUBARU TOURING WAGON JF2AN 4WD 1984 - 89
TOWING CAPACITY 950KG

REMOVE TIE DOWN HOOKS.
PLACE TOWBAR UP TO VEHICLE & FIT WITH BOLTS SUPPLIED.
REMOVE REAR BUMPER BAR.
DRILL (10mm) HOLES VIA TOWBAR THROUGH CHASSIS & FEED BOLTS ON
WIRE DOWN CHASSIS & THROUGH TOWBAR. FIT NUTS ETC. & TIGHTEN.
CHECK ALL BOLTS FOR TIGHTNESS.

FITTING KIT:

7 - 8mm x 35mm BOLTS, SPRING & FLAT WASHERS.
2 - 1.1/4" x 3/8" BOLTS TO WIRE.
2 - 3/8" NUTS, SPRING & FLAT WASHERS.
1 - D SHACKLE.