

**BORONIA TOWBARS  
1/12 EDINA RD  
FERNTREE GULLY  
VIC 3156  
(03) 9752 2642.**

**SUB7/8 FITTING INSTRUCTIONS:  
LIBERTY SEDAN/WAGON**

REMOVE SPARE WHEEL.

REMOVE REAR BUMPER BAR.

MOUNT TOWBAR TO BUMPER BRACKETS AND REFIT BUMPER. USING ORIGINAL BOLTS, TIGHTEN.(ON LATE MODEL WAGONS, BUMPER BAR INTERNAL CROSS BEAM REQUIRES A SMALL SECTION TO BE CUT OR GROUND THUS ALLOWING TOWBAR SIDE ARMS TO SIT FLUSH ON BUMPER BRACKETS). (NOTE – ON LATER MODELS, BUMPER BAR UNDER CAR SECTION HAS TO BE CUT TO ALLOW TOWBAR CENTRE UPRIGHT TO FIT. (SEDAN BUMPER CUT APPROX 65mm, WAGON CUT APPROX 90mm, SIT TOWBAR ON BUMPER BAR BRACKETS & MARK AREA THAT NEEDS TO BE CUT.)

DRILL (10mm) HOLES VIA TOWBAR TAIL SECTION INTO SPARE WHEEL AREA, FIT BOLTS COMPLETE WITH PLATES THEN SPRING WASHERS AND NUTS – TIGHTEN.

REFIT REAR BUMPER.

**FITTING KIT:**

2 – 11/2 x 3/8 BOLTS, NUTS, SPRING & FLAT WASHERS.

2 – 10 x 45mm BOLTS, NUTS, STAR & FLAT WASHERS. (WAGON ONLY)

2 – 10mm HOLE PLATES.

1 – SPACER PLATE. (SUIT LATE MODEL WAGON).

1 – DEE SHACKLE.