

**BORONIA TOWBARS P/L
1/12 EDINA RD
FERNTREE GULLY
VIC 3156
(03) 9752 2642**

**SUB9 & SUB14 FITTING INSTRUCTIONS
LIBERTY SEDAN / WAGON**

REMOVE REAR TAIL LIGHTS.
REMOVE REAR BUMPER BAR.
REMOVE & DISCARD ALUMINIUM CRASH SUPPORT PANEL.
LOOSEN REAR BUMPER BAR BRACKETS.
MOUNT TOWBAR TO BRCKETS VIA EXISTING STUDS, REFIT NUTS &
TIGHTEN.
TIGHTEN REAR BUMPER BRACKETS.
FIT 16mm BOLT SUPPLIED TO CENTRE TOWBAR SUPPORT WITH SPRING
WASHER & PLATE, TIGHTEN.
A SECTION OF THE CENTRE OF THE REAR BUMPER BAR HAS TO BE CUT
SO BUMPER CAN BE REFITTED, PLACE REAR BUMPER IN POSTION &
AND MARK AREA TO BE CUT (APPROX 80mm ACROSS x 25mm IN).
REFIT BUMPER BAR.
REFIT REAR TAIL LIGHTS.

FITTING KIT:

1 – 16 x 45mm BOLT, SPRING & FLAT WASHER.
1 – 16mm PLATE.
1 - DEE SHACKLE.