

BTA Towing Equipment

Australia's Towing Equipment Specialist



Fitting Instructions: SUB016

Vehicle: Subaru Liberty Wagon MY10 (09/2009 – on)

Subaru Outback Wagon MY10 (2009 – on)

Towing Capacity: 1250kg (Liberty) / 1500kg (Outback)

Fitting Kit:

- 2x 11mm hole plates
- 2x 3/8" x 1 1/2" bolts, nuts, spring & flat washers
- 1x 'D' shackle
- 2x Towbar Rating Labels

1.	Remove tail lights.
2.	Remove rear bumper.
3.	Remove crash support panel.
4.	Bend bumper centre support tag up against back panel.
5.	Mount towbar with crash support panel to rear studs (4 each side) using existing nuts.
6.	Centralise towbar and tighten.
7.	Drill via towbar 2 holes undercar (11mm), fit plates with bolts into spare wheel area, fit nuts with flat and spring washers to underside of car. Tighten.
8.	Replace spare wheel.
9.	Bumper cut required prior to refitting bumper, locate centre and cut bumper 45mm either side of centre for a distance of 110mm from base of bumper.
10.	Refit bumper.
11.	Refit tail lights.
12.	Apply Towbar Rating Labels to driver's side door sill <u>and</u> non-removable part of the towbar.